

Member State of OIML  
United Kingdom of Great Britain  
and Northern Ireland

OIML Certificate No  
R76/2006-GB1-12.02  
Revision 2

## OIML CERTIFICATE OF CONFORMITY

Issuing authority: **National Measurement Office**

Person responsible: **Paul Dixon – Product Certification Manager**

Applicant: **Società Cooperativa Bilanciali a.r.l.  
Via S. Ferrari No 16  
41011 Campogalliano  
Modena  
Italy**

Manufacturer: **The applicant**

Identification of the  
certified pattern: **DD1050, DD1050i, DD2050**

This certificate attests the conformity of the above-mentioned pattern (represented by the samples identified in the associated test report) with the requirements of the following Recommendation of the International Organisation of Legal Metrology (OIML):

**OIML R 76 - Edition 2006(E) for accuracy class: [III] and [IIII]**

This certificate relates only to the metrological and technical characteristics of the pattern of the instrument concerned, as covered by the relevant OIML International Recommendation.

This certificate does not bestow any form of legal international approval.

Important note: Apart from the mention of the certificates reference number and the name of the OIML Member State in which the certificate was issued, partial quotation of the certificate or of the associated test report is not permitted, though they may be reproduced in full.

**Issue Date:** 02 May 2013  
**Reference No:** T1138/0018

  
**Signatory:** P R Dixon

National Measurement Office | Stanton Avenue | Teddington | TW11 0JZ | United Kingdom  
Tel +44 (0)20 8943 7272 | Fax +44 (0)20 8943 7270 | Web [www.bis.gov.uk/nmo](http://www.bis.gov.uk/nmo)

NMO is an Executive Agency of the Department for Business Innovation & Skills



The conformity was established by tests described in the associated pattern evaluation report P00780 which includes 13 pages.

This revision replaces earlier versions of the certificate.

### **Characteristics of the instrument:**

Characteristics:

This indicating devices are designated the DD1050, DD1050i and DD2050. They is designed to be used as part of a Class III or IIII non-automatic weighing instrument. They operate as single interval, multi-interval or multi-range, are self-indicating and mains or DC-powered.

Main features:

DD1050

- Stainless steel and ABS enclosure
- 10.4" graphic LCD display
- A/D conversion module (up to 4)
- Main board with processor

DD1050i

- Stainless steel enclosure
- 10.4" graphic LCD display
- A/D conversion module (up to 4)
- Main board with processor
- Enclosed external power supply

DD2050

- Stainless steel enclosure
- 10.4" graphic LCD display
- A/D conversion module (up to 4)
- Main board with processor

Devices:

- Initial zero setting
- Semi-automatic zero setting
- Zero tracking
- Automatic zero setting (negative load indications for more than 5 s)
- Semi-automatic subtractive tare weighing
- Determination of stability of equilibrium
- Indication of stability of equilibrium
- Zero indicator
- Preset tare
- MPP Alibi storage device
- Up to 4 load receptors
- Load receptors summation
- "Weighbridge modes":
  - AdR (or RDA): stores vehicle information except weights IN and OUT
  - RcD: unknown vehicles, stores weight IN until weight OUT captured, record then deleted
  - RpD (or RCP): stores vehicle information including weight IN

- Identification and recognition of the weighing board(s): the instrument records the A/D Converter unique identification number for each weighing channel, a new calibration is required if that number is not recognised at power up
- Identification and recognition of the digital load cells and junction box type DILINK: the instrument records the unique S/N of each digital load cell and/or the A/D Converter unique identification number of DILINK junction box for each weighing channel, a new calibration is required if these numbers are not recognised at power up
- Weight data transmission in open networks or wireless transmission in protected mode utilising protocols complying with Welmec 7.2 (encrypted transmission of weight data to a remote indicator). The load receptor and the indicator displaying the weighing result must be simultaneously visible to the operator (directly or indirectly) in this configuration.
- Optional connection to an external PC and subsequent printing of measurement data from the PC using the data from the MPP Alibi storage device on the indicator
- DD2050: optional connection to an external PC allowing printing of measurement data stored on an external PC using the data from the MPP Alibi storage device on the indicator, using the integrated printer on the DD2050
- Connection to digital load cells type CPD-M
- Connection to smart junction box type DILINK

Technical data:

Power supply	110 – 240 VAC, 50 / 60 Hz 12 VDC
Maximum number of scale intervals	6000 for single interval, Class III 4000 for multi-interval/range (2 partial ranges), Class III 3000 for multi-interval/range (3 partial ranges), Class III 1000 for single and multi-interval/range (2 and 3 partial ranges), Class III
Maximum tare	- Max
Maximum Preset Tare	- Max (single and multi-range) - Max <sub>1</sub> (multi-interval)
Load cell excitation voltage	9-10 VDC (10-18 VDC for digital load cells)
Minimum load cell impedance	29 Ω (per weighing module)
Maximum load cell impedance	1100 Ω
Minimum input voltage per scale interval	0.6 μV
Measuring range minimum voltage	0 mV
Measuring range maximum voltage	27-30 mV
Fraction of maximum permissible error	P <sub>ind</sub> = 0.5 (P <sub>ind</sub> = 0 for digital load cells) (P <sub>ind</sub> = 0 for analogues load cells with junction box DILINK)
Operating temperature range	-10°C / +40°C
Load cell connection (analogue load cells)	6-wire shielded Max length 3,358 m/mm <sup>2</sup>

Load cell:

Any compatible load cell(s) may be used providing the following conditions are met:

- There is a respective OIML Certificate of Conformity (R60) issued for the load cell.
- The certificate contains the load cell types and the necessary load cell data required for the manufacturer's declaration of compatibility of modules, and any particular installation requirements. A load cell marked NH is allowed only if humidity testing to R76 has been conducted on this load cell.
- The compatibility of the load cells and indicator is established by the manufacturer by means of the compatibility of modules calculation at the time of verification.
- The load cell transmission conforms to a standard type.

Digital load cells type CPD-M and junction box type DILINK may be connected to the indicator.

Interfaces:

- Load cell 6-wire shielded connection (analogue/digital)
- RS232/422/485
- Ethernet
- USB
- 0-10 V / 0-20 mA analogue output
- Digital I/O
- Profibus
- USB host
- SD Card
- Audio

Sealing (physical or software means):

- Physical sealing: access to the calibration and metrological configuration is only possible via a protected switch located on the instrument.
- Software sealing: access to the calibration and metrological configuration shall be password protected, with any change to the calibration and metrological parameters incrementing a non-resettable counter. The counter is designated "SW seal counter" and can be displayed via the software menus. Changes are also logged on the instrument and can be viewed by the user.

### Certificate History

ISSUE NO.	DATE	DESCRIPTION
R76/2006-GB1-12.02	02 March 2012	Certificate first issued
R76/2006-GB1-12.02 rev 1	15 May 2012	Load cell excitation voltage and measuring range maximum voltage values corrected in technical data table.
R76/2006-GB1-12.02 rev 2	02 May 2013	Cable length modified in technical data table.